



GREENSTREAK GROUP, INC.

# X-Plug<sup>®</sup> Accessories

X-Plug<sup>®</sup> is easy to install and requires just a few simple tools. In addition to a standard drill, a cleaning brush and extension socket are all the tools needed to install X-Plug properly.



## Taper Tie Void Brush

The tie hole void needs to be clear of all loose debris and a taper tie void brush is recommended and available from Greenstreak.

Void brushes are 36" in length and offered in three diameters:

Cat. No. XPBR01.....1-1/2" Diameter

Cat. No. XPBR02.....1-1/4" Diameter

Cat. No. XPBR03.....1" Diameter



## Deep Extension Sockets

X-Plugs are to be centered in the wall and require an extension socket attachment to place them with a standard drill. Greenstreak's Deep Extension Socket can place X-Plug properly in walls up to 26" thick.

Cat. No. XPST01

**Please call 800-325-9504 or 636-225-9400 or send email to [info@greenstreak.com](mailto:info@greenstreak.com) for more information regarding X-Plug and X-Plug accessories.**